

SELECCION DE SISTEMA DE SENSORES (sistema.controlador)														
0: para 3.15, 4.15, 4.31, 3.36, 4.36, 4.41, 4.51 (FRENADA CORTA)														
1: para 2.15, 2.31, 2.36, 2.51														
2: para 1.15, 3.31, 1.36, 3.51														
3: para 7.15, 7.36, 5.51														
4: para 6.51														
5: para 5.15, 3.41, 5.36														
6: para 6.15, 2.41, 6.36														
7: para 8.15, 8.36														
8: para 4.51AV														
9: para 5.51AV														
10: para 9.15, 9.36														
11: para 10.15														
12: para AUX15														
13: para 3.15, 4.15, 4.31, 3.36, 4.36, 4.41, 4.51 (FRENADA LARGA)														
DISPOSICION DE BORNES DE SENSORES SEGÚN SISTEMA														
Borne	0	1	2	3	4	5	6	7	8	9	10	11	12	13
s8														
s7	exs	exs	exs		exs	exs	exs		exs	exs	exs	exs		exs
s6	pas	pn	pn	pas	pas	pas	pas	pas	pas	pas	pas	pava	ssup	pas
s5									prexs	sns				
s4	zd						pniv		zd		zd			zd
s3									prexd	sin				
s2	pad			pad	pad	pad	pad	pad	pad	pad	pad	pniv	sinf	pad
s1	exd	exd	exd		exd	exd	exd	exd	exd	exd	exd	exd	sini	exd